



AeroMarine Products, Inc.
9020 Kenamar Drive #206
San Diego, CA 92121
(877) 342-8860

www.aeromarineproducts.com
info@aeromarineproducts.com

HOW TO USE AEROMARINE PRODUCTS POLYURETHANE POUR-IN-PLACE FOAM

8# per cubic foot density

Physical Properties:

Parallel to Rise Compressive Strength: 95 psi

Tensile Strength: 220 psi

Shear Strength: 125 psi

Flexural Strength: 335 psi

R Value: 5.6 per inch

****You MUST wear a respirator or self-contained breathing apparatus when working with pour foam.****

This is NOT a sprayable foam.

Material

AeroMarine Pour-in-Place Foam is a two part, 8 LB per cubic foot density foam. Our 8# foam is a tougher foam, with thicker cells walls that can support more weight. It is an excellent insulator for use around fridges and freezers and can be sanded into any shape once cured. 8# foam works well as a casting resin, for simulated wood and for special effects. Pour-In-Place Foam can be covered with polyester resin mat and woven roving or epoxy resin with cloth, to give a strong and durable finish. ***DO NOT USE 8# FOAM FOR FLOATION!**

Mixing

Pour-In-Place Foam is mixed in a 1:1 ratio, mixing only small amounts at one time. Mixing time is approximately 20 - 30 seconds and working time is one minute. The foam will fill about 1/4 cubic foot per quart of mixed liquid at 72 F. If the foam is mixed at a lower temperature, it will be much denser and more product will be needed to complete the job.

Application

AeroMarine Pour-In-Place Foam is designed for use in filling cavities and voids. It cannot be free formed and therefore must be contained on all sides in order to completely fill the void. If a release off the surface is required, a poly sheet such as a garbage bag should be used due to the excellent adhesive quality of the foam.

Example

When filling a boat hull between stringers, mix a cup of each component in a clean container. Mix rapidly for 20 - 30 seconds and pour into the deepest part of the cavity. If the floor board is not glassed in place, wrap a poly garbage bag around it and place it on top of the stringers. The foam will expand upwards, hit the floor board and start to fill the remainder of the cavity. Simply repeat this procedure until the cavity is filled and glass the floor board in place.

Clean Up

The "A" part of the foam cleans up with acetone and the "B" part with water. Due to the adhesive quality of the foam, keep the mixed product off everything except the job itself.

Tips

- Heat closed containers in hot tap water if air temperature is lower than 65F.
- Only mix small quantities of Part "A" and Part "B" at one time.
- Heat the cavity the foam is to be poured into, if it is cold to the touch.

AeroMarine Products (seller) make no warranties, express or implied, including, but not limited to, any implied warranty of merchantability or fitness for a particular purpose. User is responsible for determining whether the seller's product is fit for a particular purpose and suitable for a user's particular method of application. Many factors can affect the use



AeroMarine Products, Inc.
9020 Kenamar Drive #206
San Diego, CA 92121
(877) 342-8860

www.aeromarineproducts.com
info@aeromarineproducts.com

and performance of seller's product. Given the variety of factors that can affect the use and performance of seller's product, some of which are uniquely within the user's knowledge and control, it is essential that the user evaluate the seller's product to determine whether it is fit for a particular purpose and is suitable for the user's method of application. If the seller's product is proven to be defective, THE EXCLUSIVE REMEDY, AT SELLER'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT. Seller shall not otherwise be liable for loss or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted, including, but not limited to, contract, negligence, warranty, or strict liability.

FOR PROFESSIONAL OR INDUSTRIAL USE ONLY